




View B



Section SS-SS  
Scale 1:1  
(4 places)



Detail of View A  
(Position of origin of joint 3 and 4.)  
Scale 1:1

# indicates mechanical stop position

Space for Connector

	GX8-A452S	GX8-A453S	GX8-A552S	GX8-A553S	GX8-A652S	GX8-A653S
a	200	200	300	300	400	400
b	200	330	200	330	200	330
c	99	-31	99	-31	99	-31
d	709	834	709	834	709	834

A  
B