



411339800

Notes on Using a Network Projector

The built-in "Network Projector" function of Windows Vista imposes the following restrictions on connection/projection.

1. A PC running Windows Vista can support the connection of one projector.
2. Turn on the power to the projector, and then press the [EasyMP] button on the remote control. The standby screen appears, and you can use the Network Projector function to set up a connection.
3. A projector cannot be connected to a PC with a video output resolution in excess of XGA (1024 x 768).
4. A Windows Photo Gallery slideshow cannot be projected in full-screen mode.
5. When using the optional network projector function of the Meeting Space function, set the display color quality on the PC to "Highest (32-bit)."

For details on items 3 and 4 above, contact the nearest address provided in the Epson Projector Contact List of the Support and Service Guide.

使用网络投影仪注意事项

Windows Vista 的内置“网络投影仪”功能在连接 / 投影方面有以下限制。

1. 运行 Windows Vista 的计算机可以支持连接一部投影仪。
2. 开启投影机电源，然后按一下遥控器上的 [EasyMP] 按钮。出现待机画面，您可以使用网络投影仪功能设定连接。
3. 投影仪不能连接视频输出分辨率超过 XGA (1024 x 768) 的计算机。
4. Windows 照片库幻灯片不能以全屏模式投影。
5. 当使用会议室功能的可选网络投影仪功能时，在计算机上设定显示色彩质量为“最高 (32 位)”。

有关以上项目 3 和 4 的详情，请联系支持和维修指南的 Epson 投影仪联系清单中提供的最近地址。

使用網路投影機注意事項

Windows Vista 的內置“網路投影機”功能在連接 / 投影方面有以下限制。

1. 運行 Windows Vista 的電腦可以支援連接一部投影機。
2. 開啟投影機電源，然後按一下遙控器上的 [EasyMP] 按鈕。出現待機畫面，您可以使用網路投影機功能設定連接。
3. 投影機不能連接視頻輸出解析度超過 XGA (1024 x 768) 的電腦。
4. Windows 相片圖庫幻燈片不能以全屏模式投影。
5. 當使用會議空間功能的可選網路投影機功能時，在電腦上設定顯示色彩品質為“最高 (32 位)”。

有關以上項目 3 和 4 的詳情，請聯繫支援與維修指南的 Epson 投影機聯繫清單中提供的最近地址。